

CUSTOMER COPY



FLARE™ WINDSHIELD FOR HONDA F6B

TOOLS NEEDED FOR INSTALLATION:

- 10mm box end wrench
- 8mm nut driver or 8mm socket and ratchet
- plastic putty knife

NOTE:

Klock Werks Flare™ Windshield uses all of the stock mounting hardware. Instructions lead you through removing the stock shield and hardware, and re-installing the Flare™.

QUESTIONS?



EMAIL:
info@getklocked.com
CALL: (605) 996.3700



1. Remove mirror boots from outer fairing.
2. Gently fold the mirrors forward to expose the 6mm fairing mount bolts.



5. Use a plastic putty knife or similar non-abrasive tool, gently lift the nose of the fairing off of the four grommets in the lower fairing.
6. Carefully remove front fairing and set aside.



3. Place a rag underneath the mounting bolts to help prevent them from falling into the fairing.



7. Use an 8mm wrench to loosen the windshield mounting screws and remove the stock windshield.



4. Using a 10mm wrench, remove the two mounting bolts.



8. Install your new Flare™ Windshield with the hardware removed in step 7 and torque fasteners to factory specifications.

Reference your service manual for proper windshield torque specs. Over-tightening may crack windshield material.

SEE PAGE 2 FOR VENT REPLACEMENT

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.



VENT REPLACEMENT

1. Remove the two button head fasteners holding the vent halves together
 - a. The vent shown uses a 3mm allen wrench and an 8mm socket
2. Disconnect the small plastic tab at the bottom of the vent
3. Rock the inner half up and off of the lip of the outer half and the two pieces should release from the windshield
4. Install the vent in reverse order into your new Klock Werks vented Flare™ windshield.

MORE WAYS TO KLOCK YOURSELF OUT



KLOCK WERKS KLEANING PRODUCTS

We tested many products, and found a company that would combine what we like and remove what we didn't like to create a complete Kleaning product line-up.

- // The recommended cleaner for your Flare™ Windshield
- // Proprietary concoction designed by REAL riders
- // Protects surfaces while repelling dirt

- // Complete line for all finishes
- // Clean, Shine, and protect - just about anything.



SHINE WERKS:

The recommended cleaner for your Klock Werks Flare™ Windshield, and more! Shine Werks cleans, shines and protects plastic, leather, acrylic, plexiglass, lexan, chrome, fiberglass, and paint. Dries quickly and buffs to a streak free shine!



MATTE WERKS:

Formulated to clean and protect matte and satin paint finishes. Matte Werks is a proprietary mixture of polymers that will clean away bugs and grime, and repel dirt, dust, fingerprints and smudges, all without adding gloss or greasiness.



ENGINE WERKS:

A unique water based product designed to renew the powder-coat finish on your motor. This product uses solvent free and non-flammable ingredients that are designed to deter dust and dirt from collecting on the surface of the motor.

U.S. Pat. No. D586,274; D632,235; D586,275; D633,017; D626,046; D633,018 Pat. 001050165-0001, 001050165-0002, 001050165-0003 APO No. 324093, 324094, 325192

KLOCK WERKS // GETKLOCKED.COM