

INSTRUCTION SHEET



SCOUT BILLBOARD FLARE™ FOR 2015+ SCOUT AND 2016+ SCOUT 60 (EXCEPT BOBBER)

INCLUDED COMPONENTS:

(1) Flare™ Windshield

INSTALLATION TOOLS:

- 4mm Allen Wrench
- 10mm Wrench

QUESTIONS?



EMAIL:
info@getklocked.com
CALL: (605) 996.3700



1. Protect painted surfaces with a clean soft cloth
2. Remove the windshield from the bike and disassemble
 - a. Unfasten the rubber clamps on each fork by slightly stretching the bands to release the catch on the back of the clamp (Fig 1)
 - b. Gently pull the rubber clamps off the forks (Fig 2)
 - c. Unhook the top windshield support from the handlebar and set the assembly on a soft cloth
 - d. Using an Allen wrench and a 10mm wrench, remove the four bolts holding the brackets to the windshield
3. Install your Flare™ Windshield.
 - a. Using the hardware removed in step 2d, install the brackets onto your Flare™ Windshield
 - b. Ensure you have a rubber washer on both the front and the back of the windshield (Fig 3a & 3b)
 - c. Torque fasteners to 25-40 in-lbs (Fig 4)
4. Install the windshield assembly onto the bike ensuring that the top windshield support goes under the brake line and clutch cable. (Fig 5)
5. Engage the rubber clamps around the forks and fasten the rubber straps
6. Enjoy your new Flare™ Windshield!

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.