

INSTRUCTION SHEET



FLARE™ WINGS FOR 2015+ SCOUT AND 2016+ SCOUT 60 (EXCEPT SCOUT BOBBER)

INCLUDED COMPONENTS:

- (1) Left Wing
- (1) Right Wing
- (2) Axia Clamps

INSTALLATION TOOLS:

- 4mm Allen Wrench
- 5mm Allen Wrench
- 10mm Wrench

NOTE:

QUESTIONS?



EMAIL:
info@getklocked.com
CALL: (605) 996.3700



1. Protect painted surfaces with a clean soft cloth
2. Install an Axia clamp on to the right-side wing
 - a. Unpackage one of the Axia clamps
 - b. Remove the button-head screw with the nylon and bonded washers (Fig 1)
 - c. Remove the thumb screw and one bonded washer (Fig 1)
 - d. Insert the button-head screw with a bonded washer through the hole in the wing (Fig 2)
 - e. Install the second bonded washer onto the button-head screw followed by the nylon washer (Fig 2)
 - f. Insert the long set screw in the block into the slot in the wing and start the button-head screw into the block (Fig 3)
 - g. Loosely install the bonded washer and the thumb screw onto the long set screw (Fig 4)
3. Remove the long Allen head screw and nut releasing the hoop from the block assembly
4. Following the steps on the Axia clamp installation card, install the hoop onto the right side fork tube (Fig 5)
5. Install the wing and block into the hoop and secure with the allen head screw and nut (Fig 6)
6. Secure the hardware on the wing when you find your desired angle.
7. Repeat on the left side and enjoy your Scout Wings!

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.