

**Klock Werks**

915 S. Kimball  
Mitchell, SD 57301

**Sales:** (605) 996.3700

**Email:** [info@getklocked.com](mailto:info@getklocked.com)

[www.getklocked.com](http://www.getklocked.com)



*Thank you for purchasing from Klock Werks. Please read through ALL of the instructions before beginning the installation.*

## **Klock Werks Lower Fillers (with or without Detachable Tour Pack)**

**HARDWARE INCLUDED:**

- (2) Klock Werks lower fillers
- (4) 5/16" x 3/4" hex bolts

**TOOLS NEEDED:**

1/2" wrench  
Loctite

**INSTRUCTIONS:**

Thank you for purchasing Klock Werks Lower Fillers, please take a moment to inventory your parts and installation hardware.

**TEST FIT YOUR FILLERS PRIOR TO PAINT OR POWDER COAT. Check to ensure that all holes line up and that the fillers do not contact the fender or saddlebags. Please read all the way through these instructions before beginning the installation process.**

1. Remove your saddle bags and set them aside on a soft cloth
2. If you have an antenna mounted between the rear fender and saddlebag, you will have to remove it. (We recommend Dakota Digital's Hidden Antenna: Drag Specialties number DS-250034.)
3. If you are installing a tour pack, place the lower end of the mounting rack through the hole on the filler, as shown in Figure 1.

4. Using the supplied 5/16" x 3/4" hex bolts, mount the lower filler as indicated in Figure 1. Hand tighten the bolts only.
5. If you are installing a tour pack and/or Klock Werks upper fillers, complete the installation of those parts at this time.
6. If you have installed a Klock Werks upper filler, adjust the lower filler so that the upper tab slides behind the upper filler, but does not contact it, as illustrated in Figure 1.
7. Once you are satisfied with the positioning of your lower fillers, tighten the two bolts with a 1/2" wrench.
8. Reinstall your saddle bags, locking the bail head screws back into position to secure the bags.
9. Inspect your new parts to be sure that no two painted parts are allowed to come into contact with each other. Also, check the fit of any detachable parts. The brackets and hardware that make up the rear fender and bag section of a bagger are made to be adjusted, and may require that you readjust some components after assembly.
10. Take your bike out for a test ride. When you return, check your fasteners and hardware to be sure nothing is coming loose. Readjust and tighten hardware as necessary. You may wish to use a drop of Loctite on the bolts to ensure they do not vibrate loose.
11. Enjoy your new Klock Werks fillers!

**WARNING: BEFORE OPERATING MOTORCYCLE,  
BE SURE ALL HARDWARE IS TIGHT**

