

INSTRUCTION SHEET



ERGO BARS FOR 2013 AND OLDER FLH

INCLUDED IN BOX:

Ergo Handlebars
Instruction Sheet

NOTE:

Always refer to model appropriate service manual for procedures and torque specifications

QUESTIONS?



EMAIL:
info@getklocked.com
CALL: (605) 996.3700

Note: it is not necessary to change your clutch cable or brake line length. The routing will need to be changed to allow the maximum length allowable without binding in the steering head.

1. Protect painted surfaces
2. Remove the seat
3. Disconnect the negative battery cable
4. Remove windshield and outer fairing
5. Remove ignition switch knob and fairing cap (the piece with the "spot" and "accy" switches in it)
6. Remove radio
7. Locate and disconnect the right and left side handlebar switch connectors and disassemble the connectors
8. Remove grips, front brake and clutch controls from handlebar
9. Remove switch housing and wire assemblies from handlebar
10. Loosen, but do not remove the passing lamp bar fasteners, or turn signal mounts for FLHX, to allow access to handlebar fasteners
11. Remove all four handlebar clamp fasteners and carefully remove handlebar from risers
12. Install your new Ergo handlebars into the handlebar clamp, set the angle and torque to specification
13. Guide the switch wires through the handlebar until the switch housing are fully seated
14. Reassemble the switch wiring connectors.
15. Install brake and clutch controls and check to make sure the clutch cable and brake lines are not in a bind when turning the steering head to left and right lock.
16. Reinstall all other removed components and torque to specification