

## INSTRUCTION SHEET



### FRONT SPEAKER GRILLE COVERS

#### INCLUDED IN BOX:

(1) Pair Speaker Grille Covers  
Instructions

#### NOTE:

You do not need to disconnect the wires on the speaker.

#### QUESTIONS?



**EMAIL:**  
info@getklocked.com  
**CALL:** (605) 996.3700

*You may wish to have an assistant to avoid damaging the paint during removal and reinstallation of the front fairing.*



FIGURE 1

1. Remove the front fairing.
  - a. Remove the 3 bolts located on the front along the windshield.
  - b. Remove one bolt beneath each speaker.
  - c. Remove the 2 bolts securing the front fairing to the fairing skirt, as is indicated in **Figure 1**.
2. Pull the front fairing loose and disconnect the wiring harness to the headlight and place your front fairing in a safe location to avoid damaging the paint.



FIGURE 2

3. Locate the 3 bolts on each speaker indicated in **Figure 2**.
  - a. Remove these 3 bolts that allow you to detach the speaker and plastic housing from the inner fairing.




FIGURE 3

4. Place your speaker grille over the plastic speaker housing as shown in **Figure 3**. It is recommended that you leave the black cloth on the plastic housing.
5. Reinstall the speaker. Repeat for the other side
6. Reinstall your front fairing. Ensure that you properly reconnect the wiring harness to the headlight and reinstall all 7 bolts.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.